
#### Microwave Movement Sensor

This product is fitted with a microwave movement sensor. Please see below detailed operating instructions.

## **Technical Specifications:**

Toolingar opcomouncies.						
Operating voltage		220 ~ 240V AC 50/60Hz				
Rated load		400W (Capacitive load) 800W (Resistive load)				
Stand-by power		≤0.5W				
	Ceiling mounted height: 3m	100% / 75% / 50% / 25% / 10%				
Sensitivity	Ceiling mounted height: 6m*	100% / 75% / 50%				
	Wall mounted height: 2m	100% / 75% / 50% / 25% / 10%				
Hold-time		5s / 30s / 90s / 3min / 20min / 30min				
Daylight sensor		2Lux / 10Lux / 25Lux / 50Lux / Disable				
Microwave frequency		5.8 GHz ±75MHz				
Transmitting power		1mW Max.				
Detection range	Ceiling mounted height: 3m	3- 6m (radius )				
	Wall mounted height: 1.5-2m	12-15m				
Detection angle		360° (Ceiling) / 120° (Wall)				
Working temperature		-20°C ~ 60°C				
*======================================		:				



<sup>\*50%, 75%, 100%</sup> detection sensitivity is workable when installed at 6m mounting height. Only 10%, 25% sensitivity is not able to detect motion signal.

#### Settings:

# 1. Sensitivity

Sensitivity can be adjusted by selecting the combination on the DIP switches for different

I -100%	_		1	2	3	
II - 75%		Ι	•	•	•	1
III - 50%	Û	II	0	•		
IV - 25%	Ó	III	•	0	•	;
V - 10%		IV	0	0		

_		1	2	3	
	Ι	•	•	•	100%
ׅ֝֝֡֡֡֝֡֝֡֝֡֡֝	II	0	•	•	75%
O	III	•	0	•	50%
	IV	0	0	•	25%
	V	0	0	0	10%

# 2. Hold-time

Hold-time refers to the time period that the light remains 100% on if no more movement is

I – 5s	_		4
II - 30s	M	Ι	
III - 90s	Ţ	II	0
IV – 3min	Ŏ	III	
V – 20min		IV	0
VI – 30min		V	•

	4	5	6	
Ι		•	•	5s
II	0	•	•	30s
III		0	•	90s
IV	0	0	•	3min
V		•	0	20min
VI	0	0	0	30min

# 3. Daylight sensor

Different daylight threshold can be preset on DIP switches. Light will always turn on upon movement if daylight sensor is disabled.

I – 2Lux			7	8	9	
II – 10Lux 🛔	. [	Ι	•	•	•	2Lux
III – 25Lux 📮		II	•	0	0	10Lux
IV – 50Lux $^{\circ}$		III	0		•	25Lux
V – Disable		IV	0	0	0	50Lux
		V	0	0	0	Disable*

\*Disable means the daylight sensor does not work. The sensor will turn on light once motion is detected regardless of ambient light level.

## Trouble shooting:

Malfunction Cause Remedy	Cause	Remedy	
	Incorrect light-control setting selected	Adjust daylight threshold setting	
The light will not come on	Faulty lamp	Replace lamp	
	No power supply	Check power to sensor	
The lamp is always on	Continuous movement in the detection zone	Check detection area setting	
The leave is an without any	The sensor is not mounted for reliably detecting movement	Securely mount enclosure	
The lamp is on without any identifiable movement	Movement occurred, but not identified by the sensor (Movement behind wall, movement of small object in immediate lamp vicinity etc.)	Reduce sensitivity.     Check the movement behind     walls to avoid facilities such as     water pipe, fan, which may     mis-trigger the sensor.	
The lamp will not work despite movement	Rapid movements are being suppressed to minimize malfunctioning or the detection radius is too small.	Check detection area setting	

For further information, please visit https://www.lighting-info.co.uk/77915

V4 06/06/2022

UK Manufacturer: BH17 7BY EU Manufacturer: Brilliant AG, Brilliantstrasse 1, D-27442 Gnarrenburg



Instruction manual

# Lucca Mini MW LED Bulkhead


77915





Thank you for purchasing this light fitting. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

#### Warning



Please read these instructions carefully before commencing any work.

This unit must be fitted by a competent and qualified electrician. Install in accordance with IEE Wiring regulations and current Building Regulations.

To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a circuit with a 30mA RCD fitted. If replacing an existing fitting, make a careful note of the connections.

This product contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

### Lavout

Plan the desired layout of these fittings carefully, ensuring the cables will reach the distance between the junction box and the light fitting.

Avoid locating any cables in positions that would cause a hazard. Position cables and outdoor rated junction boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.

We recommend that you use H05RN-F specification cable (not supplied) which is an outdoor grade, rubber sheathed cable.

The mains supply cable must have a minimum cross sectional area of  $1.0 \, \text{mm}^2$ .

Cables must be protected using suitable conduit or plastic trunking.

The products can be wall or ceiling mounted. If wall mounting ensure that the power supply is at the bottom.

#### Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, carefully note the position of each set of wires.


Note that the switch is turned off before installation.

Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.

- Gently pull the casing away from the shade and set aside.
- Remove the 4 fixing screws and detach the shade. Keep safe for refitting later
- Hold the product in place and mark the position of the holes. Ensure the
  wall is capable of holding the weight of the product, or if fitting to a
  ceiling, ensure there is a joist at the point of fixing to support the weight
  of the product.
- Knock out the chosen fixing holes.
- Fix into position. Take care to avoid damaging any concealed wiring and pipes. The correct fixings should be used for brick, cavity walls or plasterboard.
- · Pierce a hole in the grommet, and pull the cable through.
- · Wire as detailed wiring.

#### Wiring

- This product is double insulated and must not be earthed. If there are any incoming earth cables, they must be terminated in the spare terminal of the connection block.
- Having correctly identified the wiring from your existing light fitting, connect to the quick fit connection block in the following way:



## Check that...

- · You have correctly identified the wires.
- The connections are tight.
- No loose strands have been left out of the connection block.

# **Commissioning**

- Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.
- Refit the shade, ensuring that the seals are correctly located.
- Gently push your chosen casing onto the shade until it clips in place.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.

#### Technical data

Supply Voltage:

220-240 V∼, 50 Hz

Bulb

15W LED module (SMD), 4000K

Type: This product contains a light source of energy efficiency class **E**.



Replaceable (LED only) light source by a professional



Replaceable control gear by a professional



Conformity with all relevant UKCA Directive requirements



Conformity with all relevant EC Directive requirements.



The power supply is Double Insulated and does not require connection to an Earth circuit.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.




This product is not suitable for dimming.



This product is rated at IP65.

# **Care and Safety**

We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish. For your safety, always switch off the power supply before cleaning.



This light source is protected by a shade. This part must be replaced immediately should the shade become cracked or damaged. This fitting must not be used without the shade in place.